

USING THE SCREEN PROTECTOR

Installing the Screen Protector


1. Remove the mask film from the Screen Protector. Place a piece of adhesive tape on one corner of the film and quickly pull back. The side that is masked is installed facing the touch screen and the other side is the writing surface.
2. Clean both sides of the Screen Protector and the printer touch screen display with a slightly damp cloth and allow to dry.

WARNING

Failure to clean the screen and protector may scratch or damage your printer display.

3. Slide the edge of the Screen Protector between the printer and the screen.
4. Bow the Screen Protector slightly and slide the other edge of the Screen Protector between the printer and screen on the opposite side.
5. Use your thumbs to gently guide the Screen Protector into place at the bottom of the printer touch screen display until it covers the screen and lays flat.

Note: Be careful not to bend or crease the Screen Protector.



Removing the Screen Protector

1. Use a piece of adhesive tape to grab one corner of the Screen Protector.
6. Pull back to remove the Screen Protector from the printer display.
 - ◆ If you see dust or lint on your touch screen display, remove the Screen Protector, clean it and the printer touch screen with a slightly damp cloth and allow to dry before reinstalling.
 - ◆ "Oil spots" may appear if the Screen Protector is installed wrong side up. Remove the Screen Protector, turn it over, and reinstall.