


USING THE WRIST STRAP

A wrist strap is an option for the Pathfinder® Ultra® *Silver*, *Gold*, and *Platinum* printers. It helps to support the printer in your hand, making it easier to print and apply labels.


Attaching the Wrist Strap

To attach the strap to the printer:


1. Lay the strap out flat, with the angled sides facing up.




2. Turn the printer upside down, and place it on a table with the keypad facing you.



- 3.** Thread the right end of the strap through the right strap holder, keeping the angled part facing up. Move it down and out the side. Fold the end of the piece over, attaching it to the VELCRO®.




- 4.** Repeat step 3 for the left side of the strap.
- 5.** Turn the printer upright, stick your hand through the loop, and grab the printer's handle.



- 6.** Adjust pad as necessary.

7. If needed, tighten the strap by detach the part of the strap attached to the VELCRO (behind the pad) and pulling. Then, reattach the piece to the VELCRO.



Loosening the Wrist Strap

To loosen the strap, detach the part attached to the VELCRO (behind the pad). Doing so enables you to remove your hand.

Safety Feature

The plastic loops on either side of the strap are a safety feature. They are designed to come apart, breaking the strap into pieces, if it becomes caught on something and is pulled away.

Visit **www.paxar.com** for sales, service, supplies, information, and telephone numbers for our locations throughout the world.

TOLL FREE:

1-800-543-6650 (U.S.A.)

1-800-363-7525 (Canada)